

Changing the mode of operation of the AP1000/MC2000



The AP1000 has three modes of operation the user can access. They are as follows:

1. OP 1 which is RATE: RPM, FPM, MPM, etc
 2. OP 2 Time In Process (TIP) units. tenths of units or unit.hundreths of units
 3. OP 3 Time In Process (TIP) Minutes. Seconds.
-
1. To reset the AP1000 to use "OP 1" or RATE mode the user must:
 - a. Power down the unit.
 - b. Hold the center two buttons down. The center buttons are the **up arrow** and **left arrow** buttons.
 - c. Power up the unit while still holding the buttons down.
 - d. After the AP1000 displays "RESE" release the center two buttons. It will display "OP 1". It is now in the RATE mode (factory default).

 2. To reset the AP1000 to use "OP 2" or TIP mode which displays units, **units.**
 - a. Power down the unit.
 - b. Hold the left two buttons down. The left two buttons are the **decimal** and **up arrow** buttons.
 - c. Power up the unit while still holding the buttons down.
 - d. After the AP1000 displays "RESE" release the left two buttons. It will display "OP 2". The AP1000 is now in the OP 2 TIP mode.

 3. To reset the AP1000 to use "OP 3" or TIP mode which displays Minutes.Seconds or Hours.Minutes.
 - a. Power down the unit.
 - b. Hold the right two buttons down. The right two buttons are the **ent** and **left arrow** buttons.
 - c. Power up the unit while still holding the buttons down.
 - d. After the AP1000 displays "RESE" release the left two buttons. It will display "OP 2". The AP1000 is now in the OP 2 TIP mode.